

EZ-IO (Intraosseous Line) Placement



Step 1: Prime EZ-connect tubing with sterile normal saline



Step 2: Puncture skin with EZ-IO needle at skin insertion site



Step 3: Activate drill and gently advance needle until loss of resistance felt



Step 4: Remove stylet from catheter

EZ-IO (Intraosseous) Line Placement



Step 5: Attach primed EZ-connect



Step 6: Aspirate bone marrow into tubing and confirm easy flush



Step 7: To remove gently pull while rotating catheter clockwise